



Canon Ink Cartridge Compatibility Chart

Canon Printer Model	Compatible Cartridges
PIXMA MG2120	240 241
PIXMA MG2220	240XL 241XL
PIXMA MG3120	
PIXMA MG3122	
PIXMA MG3220	
PIXMA MG3222	
PIXMA MG3520	
PIXMA MG3522	
PIXMA MG3620	
PIXMA MG4120	
PIXMA MG4220	
PIXMA MX372	
PIXMA MX392	
PIXMA MX432	
PIXMA MX439	
PIXMA MX452	
PIXMA MX459	
PIXMA MX472	
PIXMA MX479	
PIXMA MX512	
PIXMA MX522	
PIXMA MX532	
PIXMA TS5120	
PIXMA MG2100	540 541
PIXMA MG2150	540XL 541XL
PIXMA MG2200	
PIXMA MG2250	
PIXMA MG3100	
PIXMA MG3150	
PIXMA MG3200	
PIXMA MG3250	
PIXMA MG3255	
PIXMA MG3500	
PIXMA MG3550	
PIXMA MG3600	
PIXMA MG3650S	
PIXMA MG4100	
PIXMA MG4150	
PIXMA MG4200	
PIXMA MG4250	

PIXMA MX375 PIXMA MX395 PIXMA MX435 PIXMA MX455 PIXMA MX475 PIXMA MX515 PIXMA TS5150 PIXMA TS5151	
PIXMA MG2420 PIXMA MG2520 PIXMA MG2522 PIXMA MG2525 PIXMA MG2920 PIXMA MG2922 PIXMA MG2924 PIXMA MG3020 PIXMA MG3022 PIXMA MG3029 PIXMA TS202 PIXMA TS302 PIXMA TS3120 PIXMA TS3122 PIXMA MX490 PIXMA MX492 PIXMA TR4520 PIXMA TR4522 PIXMA iP2820	245 246 245XL 246XL
PIXMA iP7220 PIXMA iX6820 PIXMA MG5420 PIXMA MG5422 PIXMA MG5520 PIXMA MG5522 PIXMA MG5620 PIXMA MG5622 PIXMA MG6420 PIXMA MG6620 PIXMA MX722 PIXMA MX920 PIXMA MX922	250 251 250XL 251XL
PIXMA iP8720 PIXMA MG6320 PIXMA MG7120 PIXMA MG7520	250 251 250XL 251XL (with Gray)
PIXMA iP7250 PIXMA iX6850 PIXMA MG5450 PIXMA MG5550 PIXMA MG5650 PIXMA MG6450 PIXMA MG6650	550 551 550XL 551XL

PIXMA MX725 PIXMA MX920 PIXMA MX925	
PIXMA MG5720 PIXMA MG5721 PIXMA MG5722 PIXMA MG6820 PIXMA MG6821 PIXMA MG6822 PIXMA TS5020 PIXMA TS6020	270 271 270XL 271XL
PIXMA MG7720 PIXMA TS8020 PIXMA TS9020	270 271 270XL 271XL (with Gray)
PIXMA MG5750 PIXMA MG5751 PIXMA MG5752 PIXMA MG5753 PIXMA MG6850 PIXMA MG6851 PIXMA MG6852 PIXMA MG6853 PIXMA TS5050 PIXMA TS5051 PIXMA TS5053 PIXMA TS5055 PIXMA TS6050 PIXMA TS6051 PIXMA TS6052	570 571 570XL 571XL
PIXMA TR7520 PIXMA TR8520 PIXMA TS702 PIXMA TS6120 PIXMA TS6220 PIXMA TS6320 PIXMA TS9520 PIXMA TS9521C	280 281 280XXL 281XXL
PIXMA TS8120 PIXMA TS8220 PIXMA TS8320 PIXMA TS9120	280 281 280XXL 281XXL (with Photo Blue)
PIXMA TR7550 PIXMA TR8550 PIXMA TS705 PIXMA TS6150 PIXMA TS6151 PIXMA TS6250 PIXMA TS6251 PIXMA TS9550 PIXMA TS9551C	580 581 580XXL 581XXL
MAXIFY	1200

MB2020
MB2120
MB2320
MB2720

[1200XL](#)